


Description

Font out door is an outdoor version of the popular Font collection. Same as for the Font collection, the outdoor collection includes eight design pieces ranging from bar stools, to dining and lounge chairs, with and without armrest. The collections are interconnected through the design which is evolved from the geometry of the circle.



Dimensions

W 167 cm, D 70 cm, H 68 cm
Seat H 38 cm, D 52.5 cm

Weight

42 kg

Packaging type

Assembled in box, plastic bag.

Number of parcels

1

Packaging dimensions

W 169 cm, D 72 cm, H 70 cm

Packaging weight

47 kg

Materials frame

- RAL 1015 on stainless steel
- Raw stainless steel
- Customized RAL colors (EUR 500 / 3750 DKK)

COM/COL

Fabric consumption: 3.2 x 1.4 m

Accessories

Plastic gliders are standard

Certification & labels

- CRIB5 approved foam as standard
- CAL117 approved foam on request

Before recycling

It is always recommended to reuse before recycling, to prolong the use-phase of the product. If the product should be recycled, please use the following instructions.

Overview of materials

The table below shows the different materials used for production of a Font chair or sofa.

FRAME Stainless steel

FRAMEFEET	HDPE (Polyethylene)
-----------	---------------------

FOAM	CMHR (Polyurathane)
------	---------------------

SEAT BASE	FSC certified plywood
-----------	-----------------------

UPHOLSTERY	Depends on choice
------------	-------------------

Recycling instructions

Unscrew the backrest from the frame, using the screws under the backrest.

Unscrew the seat from the frame, using the screws underneath the seat.

Use a scissor or knife to cut open the upholstery, and pull it off the seat and backrest.

The foam can now be easily pulled from the metal frame of the backrest, and the plywood of the seat. The materials are sorted and recycled using the instructions at the recycling facility.

Frame

To clean, simply wipe with a soft cloth using lukewarm water. Avoid the use of chemical cleaners.

Textile upholstery

For textile versions: See kvadrat.dk, nevotex.com, Gabriel or Designers Guild, for further cleaning and maintenance instructions for your chosen textile.

In general remove non-greasy stains by carefully dabbing with a lint-free cloth or sponge wrung out in clean lukewarm water. If necessary, clean by dabbing with soapy water. Finally, dab the surface with clean water. Finish by soaking up the moist from the upholstery using a clean dish towel and make sure it won't dye off and finish using a hairdryer.



FONT STOOL



FONT ARMSTOOL



FONT SOFA



FONT CHAIR



FONT ARMCHAIR



FONT LOUNGE CHAIR



FONT LOUNGE ARMCHAIR



FONT LOUNGE SOFA